

TABLE H-2
INVISIWARE RECEIVER

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
R-6-12 thru R-6-52	2652	1325
R-8-22 thru R-8-52	3248	1620
R-12-32 thru R-12-52	4595	2295

TABLE H-3
INVISIWARE RADIUS FERRULE

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
RF-4	1580	790
RF-6	2286	1140
RF-8	4092	2045
RF-10	4068	2030
RF-12	3762	1880

TABLE H-4
SWAGING FERRULE

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
F-4	1416	705
F-6	2022	1010
F-8	3134	1565
F-10	4262	2130
F-12	3560	1780

**TABLE H-5
SWAGING STUD**

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
S-4	1537	765
S-6	2652	1325
S-8	3248	1620
S-10	4595	2295
S-12	3994	1995

**TABLE H-6
ADJUST-A-JAW TENSIONER**

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
A-J62	2173	1085
A-J82	3134	1565
A-J122	4262	2130

**TABLE H-7
ADJUST-A- BODY W/ THREADED BOLT**

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
A-JTB6	2022	1010
A-JTB8	3320	1660

TABLE H-8
ADJUST-A-BODY W/ THREADED TAB

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
A-JTE62	2120	1060
A-JTE82	3364	1680

TABLE H-9
FIXED JAW

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
F-J62	2317	1155
F-J82	4010	2005
F-J122	4315	2155

TABLE H-10
FIXED TAB

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
F-T6-5B	2317	1155
F-T8-5B	4010	2005

TABLE H-11
INVISIWARE THREADED TAB

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
TT-6B	2120	1060
TT-8B	4262	2130

TABLE H-12
WELDED RECEIVER

Part No.	Average Ultimate Load (lbs.)	Allowable Load (lbs.)
W-R6-5A	2106	1050
W-R8-5A	2335	1165

— END OF SECTION H —